

UV Purification Systems

Technical Info

UV-3000

Exploded Diagram & Parts List

Item	Part No.	Description
1	4-BE-800WL30-1/2	Ballast
2	10-5	Set Screw
3	8-40	Black End Cap
4	8-301	Quartz Compression Nut
5	11-10	Lamp O-ring 19x6
6	RL-100/1197T6	UV Lamp
7	RQS-1190	Quartz Open Sleeve 32x36x1190
8	11-324	Quartz Sleeve Seal 2-324
9	8-30	End Flange
10	8-302	Threaded End Bushing



Item	Part No.	Description
11	8-28	1-1/2" NPT 316 SS inlet/outlet Port
12	8-10	Viewport Outer Bushing
13	7-15GL	Glass Viewport Disc
14	8-9	Viewport Compression Nut
15	5-3	Mounting Feet
16	11-6	Glass Disc Seal/Lamp O-ring 2-113
17	8-11	Viewport Inner Bushing
18	8-303	UV3000 Chamber
19	4-2	Lamp Connector